
XMD SunVisor Installation

Contents of package:

- 1 x XMD Delphi SkyFi SunVisor
- 2 x 8/32 5/8" Stainless steel screws
- 2 x 8/32 Stainless Hex nuts

Tools needed other than those found in the BMW toolkit:

- None

Note: This product is designed to fit on the Delphi SkyFi XM Satellite Radio.

Attaching the SunVisor:

- If you already have a Delphi unit installed on the bike, remove the two upper screws, washers and locknuts that attach the Delphi cradle to the extension arm.
- Use the two 5/8" screws (supplied) and the non-locking Hex nuts (supplied) to attach the cradle to the extension arm – upper holes. Use locktite to secure the hex nuts if required.
- Insert the Delphi unit into the cradle, ensuring that the lock at the rear is secure.
- Place the SunVisor on top of the Delphi unit, sliding the slots at the rear over the exposed 5/8" screws.
- Secure the SunVisor using the locknut and washers that were supplied with the extension arm.

